


# TOUCH SCREEN CONTROLLER REMOTE WIRING

(EXAMPLE AMX OR CRESTRON. ETC.)

SERVICE MODE: Lift will lower to SERVICE Position

SHOW MODE: Lift will lower to SHOW Position



## Note:

1. Program a release of relays to stop up and down.
2. Program a time out after the normal run time is exceeded.
3. Program an exclusive lockout on up and down so both the up and down cannot be activated at the same time.
4. Hold relays on to move lift, and release to stop lift.

## IMPORTANT

Not to be used with SVS Accessories:

- #4 Power Sensor
- #5 Power Sensor with Screen Control
- #15 12 Volt Trigger

© COPYRIGHT		SVS, INC.		
DRAWN BY:	C.H.	11-92	PROJECT	
CHECK BY:	C.H.	11-92	PROJECTOR LIFT	
DESIGNED BY:	SVS, INC.	11-92	DRAWING NO.	DESCRIPTION
CAGE CODE:	0KPR7	2-89	TCWIRE5	TOUCH SCREEN WIRING
PHONE	850-522-4747	REVISION	RELEASE DATE	SER # AND UP
		5	7-00	400